

Digital Shore Durometers

Model No. PHT-960 Shore A scale

Model No. PHT-980 Shore D scale



Operation Manual



283 Veterans Boulevard • Carlstadt NJ 07072
 Tel: (201)933-6300 • Fax: (201)933-3801
 E-Mail: phase2@comcast.net
 Web Site: <http://www.phase2plus.com>

Operation:

Press the On/Off button to power the unit on.

The hardness value displayed should read “000” HA(HD). If any other value is displayed, press the Zero button to clear. To check accuracy, manually place the indenter of the gage on a calibration block. Slowly press the gage down until the foot of the gage is flat on the surface for 1 second. At that time, the reading should be within +/- 2Ha points of the actual value.

Hold Feature:

Follow above procedure and press the H button when taking a test. This will hold that value until you press H again to return to zero.

Features:

- Measuring range: 0-100HSA (0-100 HSD)
- Deviation: <1%H
- Resolution: 0 .5H
- Digital read out
- Auto Hold feature
- Accurate and repetitive deviation = 20~90HSA
HSA<+/-1grade
- Conforms to ASTM D-2240, ISO 7619, DIN 53505 standards
- Uses 1-SR44 Button Cell Battery
- Custom carry case

Calibrated Test Blocks: (Call 201- 933-6300 to order)

Model No.	Description
PHT950-25	7pc Master Test Block Kit (Shore “A”)
PHT975-25	3pc Master Test Block Kit (Shore “D”)



283 Veterans Boulevard • Carlstadt NJ 07072

Tel: (201)933-6300 • Fax: (201)933-3801

E-Mail: phase2@comcast.net

Web Site: <http://www.phase2plus.com>

Global Connections



Main Headquarters: U.S.A

Phase II Machine & Tool, Inc.

283 Veterans Blvd

Carlstadt, NJ. 07072 USA

Tel: (201) 933-6300

Fax: (201) 933-3801

General E-Mail: phase2@comcast.net

BEIJING, CHINA

Phase II Measuring Instruments (Beijing) Ltd.

Room 1204,Bldg 13,Yong Tai Yuan,Qing He,Haidian District, Beijing 100192,China

[Tel:+86-10-82752121](tel:+86-10-82752121)

Fax:+86-10-82750352

General E-mail: info@phase2china.com.cn

MEXICO

Phase II de Mexico

Calle A No. 4 Promer Piso

Col. San Marcos Azcapotzalco

C.P 02020 Mexico

Tel: 011-525-5538-39771

Fax: same

General E-mail: phase2mexico@hotmail.com

VENEZUELA

Phase II Herramientas Universales EDCM. CA.

Av. Francisco Lazo Marti CC

Plaza Santa Monica PB Local

Santa Monica, Caracas 1040 Venezuela

Tel: 212-690-28-21

Fax: 212-693-29-16

E-mail: edcphm@movistar.net

• Coating Thickness • Hardness testers • Ultrasonic thickness • Surface Roughness •