



3194 MOTOR/HARMONIC HITESTER

Power Measuring Instrument





All the functions you need for motor evaluation and harmonic analysis!



3194 MOTOR/HARMONIC HITESTER provides analysis of high-order harmonics up to the 3000th order. This makes it ideal for analyzing and evaluating the performance of inverter motors and for harmonic analysis of household appliances.

Additionally, with the optional **9603-01 EXTERNAL SIGNAL INPUT UNIT** installed, the HiTESTER can directly measure torque and rotation speed, an essential feature for evaluating the performance of inverter motors. This makes it easy to construct measurement systems.











Analysis Station Extends Reach of Motor Evaluation!

■ 3194 Performs Comprehensive Evaluation of 3-phase Inverter Motors





Harmonic Waveform Analysis Functions

Features

Capable of measuring carrier frequencies on the secondary side of inverters. Also allows analysis to be synchronized with motor rotation.

: Single-phase 2- and 3- wire, three-phase 3- and 4-wire No. of channels Up to 3 channels from channels 1 to 6, depending on 3194 wiring mode

: Floppy disk, RS-232C/GP-IB, printer Output functions

: Fundamental frequency: 10 Hz to 4.5 kHz Harmonic Waveform Analysis Functions

Measurement method

: PLL or external clock

A/D resolution 12 bits

Windowing type Rectangular tiling (with gap between windows)

Crest factor : Up to 2.5 (voltage, current) PLL source

: U, I or external synchronization of the selected measurement

External

Input to a rear panel control terminal on the 3194 main unit Input level: 1V to 10 Vrms (for sine waves) synchronization

Division function: 1/1 to 1/255 signal Measurement

RMS voltage, RMS current, effective power value, items frequency, ±Upeak, ±Ipeak

Harmonic wave Harmonic level, percentage and phase angle of harmonic

measurement items wave, Total harmonic distortion (THD-F, THD-R) Screen displays : List, graph, vector and waveform displays Functions

Wiring conversion Δ -Y voltage conversion, Y- Δ voltage conversion Sorts according to decreasing order of analysis, displays up to 50th order Sort function

Averaging function : Index average with time constant of 1.5 sec

Frequency ranges:

	Fundamental Frequency	Sampling speed (Hz)	Window Width	Analysis Order
	10 - 17.5 Hz	f×8192	1 waveform	3000 (10kHz or less)
	17.5 - 35 Hz	f×8192	1 waveform	3000 (10kHz or less)
	35 - 70 Hz	f×8192	1 waveform	3000 (100kHz or less)
PLL	70 - 140 Hz	f×4096	2 waveforms	1500 (100kHz or less)
Synchronization	140 - 280 Hz	f × 2048	4 waveforms	800 (100kHz or less)
Ranges	280 - 560 Hz	f × 1024	8 waveforms	400 (100kHz or less)
	560 - 1120 Hz	f× 512	16 waveforms	200 (100kHz or less)
	1120 - 2240 Hz	f× 256	32 waveforms	100 (100kHz or less)
	2240 - 4500 Hz	f× 128	64 waveforms	50 (100kHz or less)
Fixed clock		50 × 8192 Fixed	2 waveforms	3000 (100kHz or less)

Note 1: Analysis order accuracy is restricted to the frequency in brackets.

Note 2: With PLL synchronization in the range of 10 to 35 Hz, an anti-aliasing filter of about 15 kHz is used, and with PLL synchronization in the range of 35 Hz to 4.5kHz, an anti-aliasing filter of about 120 kHz is used.

Graph Display of Harmonics

The secondary fundamental components and the carrier component level of the inverter can be observed at a glance.

Waveform Display Voltage and current waveforms are displayed. Simultaneous 3 channel display of RMS and peak values along with voltage and current waveforms is possible. [Simultaneous 3-channel display applies only in the case of 2-phase 3-wire (3-voltage 3-current)





List Display of Harmonics

Voltage, current and power are analyzed and amplitude, component ratios, and phase angle are shown numerically. Up to 50 harmonic levels are displayed in order of decreasing size by the sort function. Sections having lar ge harmonic components can be easily determined.



Sort display in order of maximum value

9603-01 EXTERNAL INPUT UNIT SPECIFICATIONS (Optional)


Features


and 3-phase 4-wire.]


Torque, rotation speed, and motor power can be measured by inputting analog torque and rpm signals to the Further, an input terminal is provided for use with a strain gauge-type torque sensor.

9603-01 EXTERNAL INPUT UNIT

- Direct connection to a strain gauge-type torque sensor is possible. (No external amplifier is necessary)
- The strain gauge input terminal has a sense function, and is not easily affected by changes in sensor cable length.
- · Zero correction function is provided for strain gauge input.










Outline of Option Specifications

■ Input Unit Specifications

Input Onit Specifications						
	9600 AC/DC DIRECT INPUT UNIT			9601 AC DIRECT INPUT UNIT		
	Voltage	Current	Power	Voltage	Current	Power
Measurement range	6.0000/15.000/30.000/ 60.000/150.00/300.00/ 600.00V/1.0000kV	200.00/500.00mA/ 1.0000/2.0000/5.0000/ 10.000/20.000/50.000A	Depends on combination of voltage and current ranges	60.000/150.00/300.00/ 600.00V/1.0000kV	200.00/500.00mA/ 1.0000/2.0000/5.0000/ 10.000/20.000/50.000A	Depends on combination of voltage and current ranges
Max operating input (55Hz)	1000Vrms/1500V peak	65Arms/100Apeak		600Vrms/850V peak	65Arms/100Apeak	
9602 CLAMP INPUT UNIT						

	Voltage	Current	Power
Measurement range	6.0000/15.000/30.000/60.000/150.00/300.00/600.00V	500.00mA to 500.00A (Depends on clamp-on sensor)	Depends on combination of voltage and current ranges
Max operating input	600Vrms/850V peak	Depends on clamp-on sensor	




Ordering Information

3194 MOTOR/HARMONIC HITESTER(main unit only)

Measurements cannot be taken with a 3194 MOTOR/HARMONIC HiTESTER unit only. A factory option unit, $9600 \sim 9604$, 9603-01 must be purchased. In the event of unit replacement or extension, the work involved is done at the factory, and unit cost + service fee are charged. Selection should be made with care from the measurement line table below.

	1ch	2ch	3ch	4ch	5ch	6ch
Pattern A	1¢2W ()	1¢2W ()	1¢2W ()	1¢2W ()	1¢2W ()	1¢2W ()
Pattern B	1\phi 3W / 3\phi	3W (×2)	1¢2W ()	1¢2W ()	1¢2W ()	1¢2W ()
Pattern C	1¢3W / 3¢3	3W (×2)	1\phi 3W / 3\phi	3W (×2)	1¢2W ()	1¢2W ()
Pattern D	1¢3W / 3¢3	3W (×2)	1\phi 3W / 3\phi	3W (×2)	1\phi 3W / 3\phi	3W (×2)
Pattern E	3¢3W	/ (3V3A) / 3ф4W (×3)	1¢2W ()	1¢2W ()	1\psi 2W ()
Pattern F	3¢3W	/ (3V3A) / 3ф4W (×3)	1\phi 3W / 3\phi	3W (×2)	1¢2W ()
Pattern G	3¢3W	/ (3V3A) / 3ф4W (×3)	3¢3W	/ (3V3A) / 3ф4W (×3)

(): 9600, 9601, 9602 can be selected.



Notes on input unit selection

- Use the same input unit for a particular measurement line.
- Units are installed in sequence starting from channel 1. If there is a blank, the blank is filled with a blank panel for shipment.
- For the 9603-01 and 9604, only one unit can be installed.
- When the 9602 is selected, use one of the optional clamp on sensors.

■ Options (factory-installation only)

(Specify at time of order)

9600	AC/DC DIRECT INPUT UNIT
9601	AC DIRECT INPUT UNIT
9602	AC/DC CLAMP INPUT UNIT *
9603-01	EXTERNAL SIGNAL INPUT UNIT
9604	PRINTER UNIT

* The voltage cable is not supplied. Contact your dealer when it is necessary to use the clip type leads.

Options

** (9270	CLAMP ON SENSOR (AC 20A)		
** (9271	CLAMP ON SENSOR (AC 200A)		
** (9272	CLAMP ON SENSOR (AC 20/200A)		
9	9277	UNIVERSAL CLAMP ON CT (AC/DC 20A)		
9	9278	UNIVERSAL CLAMP ON CT (AC/DC 200A)		
** (9279	UNIVERSAL CLAMP ON CT (AC/DC 500A)		
9	9709	AC/DC CURRENT SENSOR (AC/DC 500A)		
9	9290-10	CLAMP ON ADAPTER (AC 1500A 10:1)		
9	9232	RECORDING PAPER (10m, 10 rolls, For 9604)		
** No CE marking				

DISTRIBUTED BY



The Right Source For Your Test & Measurement Needs

2232 Verus Street Suite D San Diego CA 92154 USA
Toll Free: 866.363.6634 Tel: 619.429.4545 Fax: 619.374.7012
Email: sales@calright.com http://www.calright.com