

APM CPF Series Advanced Pressure Module





Expand Your Multi-Purpose Signal Calibrator

Now Measure Pressure!

HE CRYSTAL APM CPF SERIES pressure module, with integrated CPF * female connection, offers the functionality and flexibility to perform pressure calibrations with a multifunction signal calibrator. In addition, when connected to a hand-held pressure calibrator, the APM can expand its pressure range.

The APM is engineered to deliver the same high level of accuracy whether in the lab or in the field. Combined with calibrators and pump systems, the Crystal APM is a powerful calibration tool.

Key Features

- ► Accuracies to 0.025% of Reading. Performance to meet almost any calibration and measurement task.
- ► Seven Ranges Available. Full coverage from vacuum to 15 000 psi/1000 bar.
- ► Rugged Construction. Machined aluminum housing. Engineered for rough field use almost unbreakable.
- ► Self-Contained, Intelligent Module. Calibration data is stored in the module, so any module can be combined with any compatible JOFRA indicator. No need to "calibrate" the module to an indicator.

Compatible with your existing JOFRA Calibrator When combined with these JOFRA calibrators, the APM is a powerful calibration tool. 110.0 8715 Mesa Point Terrace San Diego, CA 92154 Toll Free: 1.866.363.6634 Tel: 1.619.429.4545 Fax: 1.619.374.7012 Email: sales@calright.com http://www.calright.com The Right Source For Your Test & Measurement Needs

Crystal APM offers seamless integration with JOFRA calibrators

like the ASC Series

U.S. Patent No. 8,794,677



Lab Accuracy in the Field

Active Temperature Compensation



Count on the same accuracy at any temperature, between -20 and 50°C.

Calibrate with Confidence Anywhere



Take measurements with up to 0.025% of reading accuracy.

Crystal Engineering calibration facilities are A2LA accredited, (#2601.01) which is internationally recognized by ILAC.


Pressure Calibration with a Signal Calibrator



The Right Source For Your Test & Measurement Needs

The Crystal APM converts a JOFRA ASC400 multifunction signal calibrator to a full-featured pressure calibrator. Seamlessly integrated with <u>AMETEK</u> <u>pump systems</u>, an APM combined with an ASC-400 provides the benefits of a host of features like leak-test, pressure-switch calibration, scaling, % error calculation, and more!

FITTINGS FOR LIFE



- Purpose designed for testing.
- ➤ Self-venting weep hole alerts you before you disconnect from a pressurized system.
- Seamless connection to pneumatic and hydraulic pump systems.

Removable CPF Adapter

Shifts everyday thread wear to a replaceable adapter fitting.



8715 Mesa Point Terrace San Diego, CA 92154
Toll Free: 1.866.363.6634 Tel: 1.619.429.4545 Fax: 1.619.374.7012
Email: sales@calright.com http://www.calright.com

Specifications



Accuracy

30, 100 and 300 psi

3, 10 and 30 bar

300 kPa, 1 and 3 MPa

0 to 30% of Range ±(0.0075% of Full Scale)

30 to 110% of Range.... ±(0.025% of Reading)

Vacuum.....For 100 psi/10 bar/1 MPa and lower:

±(0.06% of Full Scale*)

For 300 psi/30 bar/3 MPa:

±(0.06% of Full Scale*) ±1 LSD

* Full Scale = -14.5 psi /-1.0 bar /-100.0 kPa.

1000 and 3000 psi

100 and 300 bar

10 and 30 MPa

0 to 30% of Range±(0.015% of Full Scale)

30 to 110% of Range.... ±(0.05% of Reading)

10 000 and 15 000 psi

700 and 1000 bar

70 and 100 MPa

0 to 30% of Range **±(0.03% of Full Scale)**

30 to 110% of Range....±(0.1% of Reading)

Includes all effects of linearity, hysteresis, repeatability, temperature, and stability for one year.

All models indicate vacuum, but vacuum specification applies only where specified.

Not recommended for continuous use at high vacuum. Refer to XP2i-DP data sheet for gauges that are intended for continuous high vacuum use.

Sensor

Wetted Materials......(WRENCH TIGHT) 316 stainless steel

(FINGER TIGHT) 316 stainless steel

and Viton® (internal o-ring)

Diaphragm Seal Fluid . . . Silicone Oil

Connection......Crystal CPF Female

All welded, with a permanently filled diaphragm seal.

Metal to metal cone seal; O-ring can be removed if necessary.

1/4" male NPT adapter is included unless BSP, M20 or 15KPSI is specified.

1/4" medium pressure tube system is compatible with HIP LM4 and LF4 Series, Autoclave Engr SF250CX Male and Female Series.

Output

Pressure Resolution up to 5 digits

Display Updateup to 10 per second

 ${\it Pressure \, resolution \, is \, the \, maximum \, resolution \, available.}$

The resolution of your JOFRA device may be different.

Communication

Serial9600 baud, 8 data, no parity, 1 stop

Protocol ASCII command language

Pressure Overload

Overload Alarm......"+OL" in display at 110% F.S.

Operating Temperature

Temperature Range.....-20 to 50° C (-4 to 122° F)

< 95% RH, non-condensing. No change in accuracy over operating temperature range. Gauge must be zeroed to achieve rated specification.

Applies to all modules.

Storage Temperature

Temperature Range.....-40 to 75° C (-40 to 167° F)

Enclosure

(35.5 x 35.5 x 76.2 mm)






Accuracies, Ranges, and Resolutions

	psi	bar	kPa/MPa	Overpressure	psi	kg/cm2	inHg	inH20	mmHg	mmH20	kPa	bar	mbar	MPa
0.025% of Reading modules	30PSI			3.0 x	0.001	0.0001	0.001	0.01	0.01	1	0.01	0.0001	0.1	
		3BAR		3.0 x	0.001	0.0001	0.001	0.01	0.01	1	0.01	0.0001	0.1	
			300KPA	3.0 x							0.01	0.0001	0.1	
	100PSI			2.0 x	0.001	0.0001	0.01	0.1	0.1	1	0.01	0.0001	0.1	0.00001
		10BAR		2.0 x	0.001	0.0001	0.01	0.1	0.1	1	0.01	0.0001	0.1	0.00001
			1MPA	2.0 x							0.01	0.0001	0.1	0.00001
	300PSI			2.0 x	0.01	0.001	0.01	0.1	0.1		0.1	0.001	1	0.0001
		30BAR		2.0 x	0.01	0.001	0.01	0.1	0.1		0.1	0.001	1	0.0001
			3MPA	2.0 x							0.1	0.001	1	0.0001
0.05% of Reading modules	1KPSI			2.0 x	0.1	0.001	0.1				0.1	0.001		0.0001
		100BAR		2.0 x	0.1	0.001	0.1				0.1	0.001		0.0001
			10MPA	2.0 x							0.1	0.001		0.0001
	3KPSI			1.5 x	0.1	0.01	0.1				1	0.01		0.001
		300BAR		1.5 x	0.1	0.01	0.1				1	0.01		0.001
			30MPA	1.5 x							1	0.01		0.001
0.1% of Reading modules	10KPSI			1.5 x	1	0.01					1	0.01		0.001
		700BAR		1.5 x	1	0.01					1	0.01		0.001
			70MPA	1.5 x							1	0.01		0.001
	15KPSI*			1.3 x	1	0.01					1	0.01		0.001
		1000BAR*		1.3 x	1	0.01					1	0.01		0.001
			100MPA*	1.3 x							1	0.01		0.001

Resolutions shown are the maximum resolutions available. The resolution of your JOFRA device may be different.

Ordering Information



SAMPLE PART NUMBERS





^{*} CPF adaptor fitting is not included. 1/4" medium pressure tube system is compatible with HIP LM4 and LF4 Series, Autoclave Engr SF250CX Male and Female Series. See our CPF data sheet for additional adapter fittings.

USA, Florida

Tel +1 (800) 527 9999 cal.info@ametek.com

USA, California*

Tel +1 (800) 444 1850 crystal@ametek.com

India

5275.B

Tel +91 22 2836 4750 jofra@ametek.com Singapore

Tel +65 6484 2388 jofra@ametek.com

China, Shanghai

Tel +86 21 5868 5111 jofra.sales@ametek.com.cn

China, Beijing

Tel +86 10 8526 2111 jofra.sales@ametek.com.cn

China, Guangzhou Tel +86 20 8363 4768

jofra.sales@ametek.com.cn

United Kingdom

Tel +44 (0) 1243 833 302 jofra@ametek.co.uk

France

Tel +33 (0) 30 68 89 40

general.lloyd-instruments@ametek.fr

Germany

Tel +49 (0) 2159 9136 510 info.mct-de@ametek.de

Denmark

Tel +45 4816 8000 jofra@ametek.com

*ISO 17025 accredited calibration lab, (A2LA #2601.01).



8715 Mesa Point Terrace San Diego, CA 92154

Toll Free: 1.866.363.6634 Tel: 1.619.429.4545 Fax: 1.619.374.7012

Email: sales@calright.com http://www.calright.com